



NOTE: mount pots so linnet is on the left. If mounted opposite, switch the wires going to mix 1 and mix 3

Above each 555, solder a short jumper wire along the line.

For no wave mod, solder a short jumper wire across the line marked "WAVE".

For wave mod, the top hole goes to the wave pot (lug 2), and the bottom hole is left open